Choosing the Correct Device for Blood Collection

These steps do not reflect the complete practice. Refer to Instructions For Use (IFU) for full details.


Category Device **Key Steps** Blood **Cultures** Note: Blood Cultures should be carried out using an aseptic technique, according to hospital policy. BD Vacutainer® Push Button Blood Collection Set - 23G **Adults**






BD Vacutainer® Eclipse™ Needle - 21G (green) 22G (black)

BD Vacutainer® Push Button Blood Collection Set - 23G











Drawing blood from a port into a blood collection tube.




BD Vacutainer® Luer-Lok™ Access Device












Safe transfer of blood from a syringe into a blood collection


tube




BD Vacutainer® Blood Transfer Device









Tourniquets and flow

As recommended by the Clinical and Laboratory Standards Institute (CLSI), the tourniquet should be applied for no longer than one minute before venepuncture is carried out, in order to avoid hemoconcentration. There must be no vigorous hand exercises ("pumping") during collection, as this can change the concentration of certain analytes in the blood.

- Clinical and Laboratory Standards Institute Guidelines GP41-A6 (formerly H3-A6, 6th Edition)

DISCLAIMER:

The information in this Best Practice Guide is provided to assist the user with certain important steps during product usage. This document does not replace the Instructions For Use (IFU), and the user should always consult the IFU provided with the product in the first instance. For further technical support or guidance, please contact your local BD representative

Order of Draw

Blood samples should be collected in the recommended sequence to prevent cross contamination between tubes, therefore preventing inaccurate results.

All BD Vacutainer® tubes require immediate mixing following collection. Insufficient mixing can result in inaccurate test results and the need to re-draw.

Correct mixing technique is to gently invert each tube 180° and back by the recommended number of times shown on the right hand side of the table below.









Sodium Citrate







Erythrocyte Sedimentation Rate (ESR)







BD Vacutainer® SST™ II *Advance*















EDTA







Crossmatch







Trace Element (EDTA)







Fluoride/Oxalate



Please note

- Coagulation/Sodium Citrate tube samples will be rejected if filled below the minimum fill line shown here.
- If using a wingset, use a discard tube first to prevent underfilling of the Coagulation/Sodium Citrate tube.



BD Life Sciences - Preanalytical Systems The Danby Building, Edmund Halley Road, Oxford Science Park Oxford OX4 4DO Tel: 01865 781529 www.bd.com